

SHARP® SERVICE MANUAL

S30333R937EHW



SUPPLEMENT MICROWAVE OVEN GRILL AND CONVECTION

R- 937(W/IN)/(IN)F


In interests of user-safety the oven should be restored to its original condition and only parts identical to those specified should be used.

This service manual covers only those items that differ from the R-933 S07283R933EHW.
For further information on items not covered by this supplement refer to the Service Manual for R-933 .


TABLE OF CONTENTS

REF No	PART CODE	DESCRIPTION	QTY	CODE
CH	RHET-A269WRZZ	Convection heating element	1	AV
CM	RMOTEA415WRZZ	Convection motor	1	AV
3-2	DPWBFA191URK0	CPU/LCD assy	1	BL
3-6	HPNLCW091URR0	Jog panel (R-937(W))	1	AR
3-6	HPNLCW091URR0	Jog panel (R-937(IN))	1	AR
3-7	GMADIA042URR0	Display window(R-937(W))	1	AG
3-8	JBTN-W037URF0	More/Less button(R-937(W))	1	AD
3-9	JBTN-S020URR0	Express/Defrost button	1	AE
3-10	JBTN-W036URR0	Stop/Watt button (R-937(W))	1	AE
3-11	JKNBKW021URF0	Select knob(R-937(W))	1	AE
3-12	JKNBKW020URF0	Timer knob (R-937(W))	1	AE
4-4	DOVN-A024URK0	Cavity assy	1	BH
4-20	PPIPFA005UR10	Pipe	1	AD
4-21	PSKR-A013URP0	Air separate angle A	1	AC
4-22	PSKR-A014URP0	Air separate angle B	1	AC
4-23	PSKR-A015URP0	Air separate angle C	1	AC
4-24	PSKR-A016URP0	Air separate angle D	1	AC
4-28	PSKR-A012URP0	Air separate angle E	1	AC
4-30	NFANMA004URP0	Convection fan	1	AE
4-32	PDUC-A019URP0	Convection duct	1	AP
5-1	CDORFS028URK0	Door assy(R-937(IN))	1	BN
5-1	CDORFW026URK0	Door assy(R-937(W))	1	BM
5-1-4	JHNDPS201URT0	Door handle (R-937(IN))	1	AW
5-1-4	JHNDPW200URF0	Door handle (R-937(W))	1	AW
5-1-10	JHNDPW205URF0	Door handle cover(R-937(W))	1	AW
5-1-10	JHNDPK205URF0	Door handle cover(R-937(IN))	1	AW
5-1-7	PGLSPA031URR0	Front door glass (R-937(W))	1	AX
5-1-9	XCTSD40P20000	Screw	2	AA
6-6	TINS-A315URR0	Operation manual	1	AS
6-7	TCADCA015URR0	Cook book (R-937(IN))	1	AU
6-12	TINS-A318URR0	Quick start guide	1	AM

JOG PANEL



DOOR PARTS






Figure S-7 Printed Wiring Of Board of Switch Unit

OVEN PARTS

